

PAPER FEED UNIT TYPE 140F

PARTS LOCATION AND LIST

PARTS CATALOG

INTRODUCTION

This section instructs you as to the numbers and names of parts on this machine.

INDEX to PARTS CATALOG


SECTION 1 PART LOCATION AND LIST

1. EXTERIOR	2
2. FRAME	4
3. CASSETTE.....	6

SECTION 2 PARTS INDEX

Parts Index	2
-------------------	---

1. EXTERIOR




1. EXTERIOR

Rev. 8/96

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3784	Cover - Connector - Upper	
2	H516 3782	Cover - Left	
3	H516 3658	Rear Stay	
4	H515 3702	Base Holder	
5	H516 3783	Cover - Rear	
6	H516 3781	Cover - Right - Rear	
7	H516 3780	Cover - Right - Front	
8	H516 3786	Panel - LED Indicator	
9	H515 5070	Display - LED	
10	H516 3675	Upper Guide	
11	H110 3851	Joint Bracket	
12	H515 3694	Right Pin Holder	
13	H515 3695	Left Pin Holder	

INDEX	PARTS NO.	DESCRIPTION	Note
101	0443 0060W	Hexagon Head Tapping Screw - M3x6	
102	0353 0080Z	Philips Trass Head Screw - M3x8	
103	0951 3006B	Philips Screw With Flat Washer - M3x6	

2. FRAME




2. FRAME

Rev. 4/96

INDEX	PARTS NO.	DESCRIPTION	Note
1	H516 3672	Lock Release Guide	
2	H516 3666	Spring - 19.6mm	
3	H516 3665	Cassette Stopper	
4	H516 3676	Guide Plate - Cassette 2	
5	H516 3655	Front Stay	
6	H515 3709	Edgeing	
7	H516 5059	Paper End Sensor - PFU	
8	H515 5068	Registration Sensor - PFU	
9	H515 3673	Registration Roller - PFU	
10	H515 3713	Paper Feed Roller - PFU - US	
11	H006 2383	Snap Ring	
12	H053 1600	Bushing - M6 : CMFE	
13	H515 3680	Idle Gear	
14	H020 3623	Snap Ring - Registration Roller	
15	H515 6030	PCB - PFU	
16	H516 5331	LED Harness - PFU	
17	H516 5330	Sensor Harness - PFU	
18	H515 5332	Lower PFU Harness	
19	H516 3332	Upper PFU Harness	
20	H516 3668	Connector Bracket	
21	H515 5065	P. F. Motor - PFU - DC24V;0.49A	
22	H516 3659	Motor Bracket	
23	H515 3679	Brake Gear	
24	H515 5066	Paper Feed Clutch	
25	H515 3681	Registration Gear	
26	H515 5054	Paper Size Sensor	
27	H515 3715	Pcb Supporter	
28	H515 3697	Cassette Rail	
29	H516 3671	Side Plate Cover	
30	H516 3669	Grounding Plate	
31	H516 3652	Lower Base Guide	
32	H516 3667	Cassette Guide	

INDEX	PARTS NO.	DESCRIPTION	Note
33	H521 3350	Rubber Foot	
34	H515 3693	Positioning Pin	
35	H516 3673	Base Mylar	
36	H516 3653	Side Plate - Right	
37	H516 3654	Side Plate - Left	
101	0443 0080W	Hexagon Head Tapping Screw - M3x8	
102	0805 3385	Bushing - 6mm	
103	1105 0344	Clamp	
104	0951 3006B	Philips Screw With Flat Washer - M3x6	
105	1105 0243	Wire Saddle	
106	0353 0080Z	Philips Trass Head Screw - M3x8	
107	0802 5231	Tapping Screw - M3x6	
108	0433 0060W	Hexagon Head Tapping Screw - M3x6	
109	0805 3384	Bushing - 8mm	

3. CASSETTE



3. CASSETTE

Rev. 5/96

INDEX	PARTS NO.	DESCRIPTION	Note
1	H515 3611	Side Fence Ass'y	
2	H515 3616	Front Paper Holder	
3	H515 3626	Paper Holder Spring	
4	H516 3470	Decal - Cassette	
5	H516 3625	Spacer - Cassette	
6	H515 3625	End Fence Stopper	
7	H515 3614	End Fence	
8	H515 3629	Spring Stopper	
9	H515 3615	End Fence Spring	
10	H516 3610	Cassette - OP - T	
11	H515 3631	Sponge	
12	H516 3612	Bottom Plate	
13	H515 3621	Rear Friction Pad	
14	H515 3620	Front Friction Pad	
15	H515 3622	Pressure Spring	
16	H515 3627	Bottom Plate Stopper	
17	H515 3632	Stopper Spring	
18	H515 3617	Rear Paper Holder (USA)	
18	H515 3638	Rear Paper Holder (EUR)	
19	H516 3618	Vertical Paper Guide (EUR)	
19	H516 3620	Vertical Guide - Registration 2 (USA)	
20	H516 3613	Front Cassette Guide	
21	H516 3616	Cassette Cover	
22	H515 3683	Pressure Roller	
23	H516 3615	Pressure Shaft	
24	H006 3533	Snap Ring	
25	H516 3614	Pressure Spring	
26	H516 3617	Paper Size Sensor Bracket	
27	H516 3422	Paper Size Sensor Board - A5	
27	H516 3428	Paper Size Sensor Board - Letter	
27	H516 3429	Paper Size Sensor Board - A4	
27	H516 3430	Paper Size Sensor Board - Legal	

INDEX	PARTS NO.	DESCRIPTION	Note
27	H516 3432	Paper Size Sensor F	
28	H515 3618	Sponge	
29	5413 4835	Decal - Paper Level	
30	H516 3621	Vertical Guide - Registration 1 (USA)	
31	H515 3623	Decal - Cassette - Upper	
32	H516 3624	Spacer - Cassette -2	
101	0802 5232	Tapping Screw - M3x8	
102	0720 0030E	Retaining Ring - M3	
103	0353 0080Z	Philips Trass Head Screw - M3x8	

PAPER FEED UNIT TYPE 140F
PARTS INDEX

This section instructs you as to the numbers and names of parts on this machine.

PART N O.	DESCRIPTION	INDEX
H006 2383	Snap Ring	5- 11
H006 3533	Snap Ring	7- 24
H020 3623	Snap Ring - Registration Roller	5- 14
H053 1600	Bushing - M6 : CMFE	5- 12
H515 0101	Side Fence Ass'y	7- 1
H515 3614	End Fence	7- 7
H515 3615	End Fence Spring	7- 9
H515 3616	Front Paper Holder	7- 2
H515 3617	Rear Paper Holder (USA)	7- 18
H515 3618	Sponge	7- 28
H515 3620	Front Friction Pad	7- 14
H515 3621	Rear Friction Pad	7- 13
H515 3622	Pressure Spring	7- 15
H515 3623	Decal - Cassette - Upper	7- 31
H515 3625	End Fence Stopper	7- 6
H515 3626	Paper Holder Spring	7- 3
H515 3627	Bottom Plate Stopper	7- 16
H515 3629	Spring Stopper	7- 8
H515 3631	Sponge	7- 11
H515 3632	Stopper Spring	7- 17
H515 3638	Rear Paper Holder (EUR)	7- 18
H515 3673	Registration Roller - PFU	5- 9
H515 3679	Brake Gear	5- 23
H515 3680	Idle Gear	5- 13
H515 3681	Registration Gear	5- 25
H515 3683	Pressure Roller	7- 22
H515 3693	Positioning Pin	5- 34
H515 3694	Right Pin Holder	3- 12
H515 3695	Left Pin Holder	3- 13
H515 3697	Cassette Rail	5- 28
H515 3702	Base Holder	3- 4
H515 3709	Edgeing	5- 6
H515 3713	Paper Feed Roller - PFU - US	5- 10

PART N O.	DESCRIPTION	INDEX
H515 3715	Pcb Supporter	5- 27
H515 3784	Cover - Connector - Upper	3- 1
H515 3790	Joint Bracket	3- 11
H515 5054	Paper Size Sensor	5- 26
H515 5065	P. F. Motor - PFU - DC24V;0.49A	5- 21
H515 5066	Paper Feed Clutch	5- 24
H515 5068	Registration Sensor - PFU	5- 8
H515 5070	Display - LED	3- 9
H515 5332	Lower PFU Harness	5- 18
H515 5333	Upper PFU Harness	5- 19
H515 6030	PCB - PFU	5- 15
H516 3422	Paper Size Sensor Board - A5	7- 27
H516 3428	Paper Size Sensor Board - Letter	7- 27
H516 3429	Paper Size Sensor Board - A4	7- 27
H516 3430	Paper Size Sensor Board - Legal	7- 27
H516 3432	Paper Size Sensor F	7- 27
H516 3470	Decal - Cassette	7- 4
H516 3610	Cassette - OP - T	7- 10
H516 3612	Bottom Plate	7- 12
H516 3613	Front Cassette Guide	7- 20
H516 3614	Pressure Spring	7- 25
H516 3615	Pressure Shaft	7- 23
H516 3616	Cassette Cover	7- 21
H516 3617	Paper Size Sensor Bracket	7- 26
H516 3618	Vertical Paper Guide (EUR)	7- 19
H516 3620	Vertical Guide - Registration 2 (USA)	7- 19
H516 3621	Vertical Guide - Registration 1 (USA)	7- 30
H516 3624	Spacer - Cassette -2	7- 32
H516 3625	Spacer - Cassette	7- 5
H516 3652	Lower Base Guide	5- 31
H516 3653	Side Plate - Right	5- 36
H516 3654	Side Plate - Left	5- 37
H516 3655	Front Stay	5- 5

PART N O.	DESCRIPTION	INDEX
H516 3658	Rear Stay	3- 3
H516 3659	Motor Bracket	5- 22
H516 3665	Cassette Stopper	5- 3
H516 3666	Spring - 19.6mm	5- 2
H516 3667	Cassette Guide	5- 32
H516 3668	Connector Bracket	5- 20
H516 3669	Grounding Plate	5- 30
H516 3671	Side Plate Cover	5- 29
H516 3672	Lock Release Guide	5- 1
H516 3673	Base Mylar	5- 35
H516 3675	Upper Guide	3- 10
H516 3676	Guide Plate - Cassette 2	5- 4
H516 3780	Cover - Right - Front	3- 7
H516 3781	Cover - Right - Rear	3- 6
H516 3782	Cover - Left	3- 2
H516 3783	Cover - Rear	3- 5
H516 3786	Panel - LED Indicator	3- 8
H516 5059	Paper End Sensor - PFU	5- 7
H516 5330	Sensor Harness - PFU	5- 17
H516 5331	LED Harness - PFU	5- 16
H521 3350	Rubber Foot	5- 33

PART N O.	DESCRIPTION	INDEX
5413 4835	Decal - Paper Level	7- 29

PART N O.	DESCRIPTION	INDEX
0353 0080Z	Philips Trass Head Screw - M3x8	3-102
0353 0080Z	Philips Trass Head Screw - M3x8	5-106
0353 0080Z	Philips Trass Head Screw - M3x8	7-103
0433 0060W	Hexagon Head Tapping Screw - M3x6	5-108
0443 0060W	Hexagon Head Tapping Screw - M3x6	3-101
0443 0080W	Hexagon Head Tapping Screw - M3x8	5-101
0720 0030E	Retaining Ring - M3	7-102
0802 5231	Tapping Screw - M3x6	5-107
0802 5232	Tapping Screw - M3x8	7-101
0805 3384	Bushing - 8mm	5-109
0805 3385	Bushing - 6mm	5-102
0951 3006B	Philips Screw With Flat Washer - M3x6	3-103
0951 3006B	Philips Screw With Flat Washer - M3x6	5-104
1105 0243	Wire Saddle	5-105
1105 0344	Clamp	5-103

PART N O.	DESCRIPTION	INDEX

